

Station 2 column

hy there! let's assemble!



assembly instruction

1



Place the Bottom Module upside-down on a clean and soft surface.

2



Align the holes in the base plate with the corresponding holes in the Bottom Module.

3



Place the threaded sleeves in the holes inside the Bottom Module. Align the slot vertically.

4



Fasten the screws in the base plate.

5



Turn the Bottom Module with base plate around and place the Top Module on top. Align the modules.

6



Press the inside threaded screws through the holes and fasten with counter screws.

7



Place the melamine tray in the slot.



www.hygn.me/service

Station 2 column

hy there! let's assemble!



Montageanleitung

1



Drehen Sie das Bottom Modul auf die Kopfseite und platzieren Sie es auf einer weichen Unterlage.

2



Legen Sie die Bodenplatte auf das Bottom Modul. Richten Sie es so aus, das die Positionen der Bohrungen übereinstimmen.

3



Platzieren Sie die Gewindehülsen in den entsprechenden Bohrungen und richten Sie die Schlitze vertikal aus.

4



Befestigen Sie die Schrauben in der Bodenplatte.

5



Drehen das Bottom Modul mit befestigter Bodenplatte um und platzieren Sie das Top Modul passgenau auf dem Bottom Modul.

6



Drücken Sie die Schrauben von oben durch die Löcher und kontern Sie diese mit den Hülsenschrauben.

7



Platzieren Sie die Melamin-Schale in der Ausfräsung.



www.hygn.me/service